

## REMORCI PENTRU CEREALE Trans-SPACE



Cod	Tip	Sarcina utila	Dimensiuni interioare bena (m)					Volum DIN (m3)	Axe: □ - ecartament-prezoane	Cilindru (l)
			Lungime dedesubt	Lungime deasupra	Latime fata	Latime spate	Inaltime			
4627	6500/18BC125	16 T	6,39	6,67	2,18	2,26	1,25	18,1	2x130x2000-10S	48
4628	6500/22BC150	16 T	6,39	6,73	2,18	2,26	1,5	21,9	2x130x2000-10S	48
4629	7000/19BC125	18 T	6,87	7,15	2,18	2,26	1,25	19,4	2x130x2000-10S	65
4630	7000/23BC150	18 T	6,87	7,2	2,18	2,26	1,5	23,5	2x130x2000-10S	65
4631	7500/21BC125	20 T	7,34	7,62	2,18	2,26	1,25	20,7	2x140x2000-10S	65
4632	7500/25BC150	20 T	7,34	7,68	2,18	2,26	1,5	25,1	2x140x2000-10S	65
4633	7500/21TRC125	22 T	7,34	7,62	2,18	2,26	1,25	20,7	3x130x2000-10S	68
4634	7500/125T RC150	22 T	7,34	7,68	2,18	2,26	1,5	25,1	3x130x2000-10S	68
4635	8000/22TRC125	24 T	8,08	8,36	2,18	2,26	1,25	22,7	3x130x2000-10S	68
4636	8000/27TRC150	24 T	8,08	8,41	2,18	2,26	1,5	27,4	3x130x2000-10S	68

**AGRIROMEX**

Splaiul Independentei nr. 17  
Sector 5, Bucuresti  
Tel: 021 316 01 65  
Fax: 021 316 01 94

**JOSKIN**